

Three Axle Air Brake System Trainer (Model 6430)



AIR BRAKE COMPONENTS:

- Low Pressure Warning Light/Buzzer
- Low Pressure Indicator Switch
- Safety Valve
- Drain Valves– Manual
- Single Check Valves
- Air Gauge
- Brake Light Switch
- Quick Release Valve
- Double Check Valve
- Dual System Foot Brake Valve
- Control Valve
- Spring Brake Valve
- R12 Relay Valve
- R14 Relay Valve
- Spring Brake
- Service Brake Chamber

The ATECH Air Brake Training System allows System Demonstrations of:

- Compressor Failure
- Primary Tank Failure
- Secondary Tank Failure
- Normal Brake Operation
- Park Brake Apply and Release

COURSEWARE INCLUDED:

- Medium/Heavy Duty Truck Brake Classroom Manual
- Medium/Heavy Duty Truck Brake Shop Manual
- Medium/Heavy Duty Truck Brake Instructor's Guide
- Dual Circuit Brake System Troubleshooting Manual
- Air Brake Systems Video
- Air Brake Systems Video Training Workbook
- Air Brake Systems Video Training Handout
- Air Brake Components Maintenance Troubleshooting Handbook

The Training System needs an external compressed air supply of 90 to 140 PSI and a standard 110 VAC electrical supply.



Air Brake Training System Courseware

Call Now to Place Your Order (Press 1 For Sales)

ATECH Training, Inc.
12290 Chandler Drive, Walton, KY 41094
Ph: (859) 485-7229 Fax: (859) 485-7299

ATech
Automotive Technology