


Tractor (Model 6410) and Trailer (Model 6420) Air Brake System Trainers



AIR BRAKE COMPONENTS INCLUDE:

- Low Pressure Warning Light and Buzzer
- Safety Valve
- Single Check Valves
- Brake Light Switch
- Double Check Valve
- Control Valve
- Relay Valve
- Spring Brake
- Tractor Protection Valve
- Service and Emergency Glad Hands
- RT2 Valve
- Quick Release and Double Check Valve Combination
- Low Pressure Indicator Switch
- Drain Valves– Manual
- Air Gauge
- Quick Release Valve
- Dual System Foot Brake Valve
- Spring Brake Valve
- Hand Control Valve
- Service Brake Chamber
- Manifold Dash Valve
- RT4 Valve
- D.O.T. Air Brake Lines

The ATECH Air Brake Training Systems are complete programs for presenting the “real world” operation and study of Three Axle and Tractor-Trailer Air Brake Systems. The trainers demonstrate FMVSS 121 Air Brake Systems.

Courseware includes Shop Manuals, Instructor’s Guide, Classroom Manual, Components Maintenance Troubleshooting Handbook, and Videos. NATEF Task Record Keeping Sheets are included with the courseware to assist the instructor in recording the progress of each student as NATEF tasks are completed.

Call Now to Place Your Order (Press 1 For Sales)

ATECH Training, Inc.
12290 Chandler Drive, Walton, KY 41094
Ph: (859) 485-7229 Fax: (859) 485-7299

ATECH
Automotive Technology